



CHADSWORTH COLUMNS

ADVANCED CELLULAR VINYL COLUMNS – FINISHING TIPS

FINISHING & PAINTING

Chadsworth's Advanced Cellular Vinyl columns, tapered and non-tapered, must be painted with two (2) coats of acrylic latex paint. Apply paint adhering to the manufacturer's painting instructions.

When installing our Advanced Cellular Vinyl columns that will have contact with direct sunlight, we recommend painting with light colors so that thermal gain does not build up – which can cause column warping.

www.COLUMNS.com