



CHADSWORTH COLUMNS



POLYSTONE® ACCENTS – FINISHING TIPS

A. PARTS AND SUPPLIES NEEDED FOR INSTALLATION

Hardware not included:

The following will need to be purchased before beginning installation.

- Standard construction adhesive
- Mineral spirits - for cleaning
- High quality primer and topcoat paint

B. PREPARATION

1. General – Good industrial/construction safety practices demand that when grinding, cutting, or sanding our products, you must work in a well-ventilated area and wear protective safety equipment, such as safety gloves, safety glasses and a MSHA/NIOSH approved respirator.
2. Installation - It is recommended that safety gloves, hard hats and safety glasses, as well as other specified safety equipment be used during installation.

C. FINISHING

1. Finish by caulking all seams and drill holes.
2. Repairs to the ornaments may be made using automotive adhesive such as Bondo®.
3. Apply a high quality primer to both the ornament.
4. Finish with a premium grade of topcoat paint.