



CHADSWORTH COLUMNS



RESIN ACCENTS – INSTALLATION

INSTALLING RESIN ORNAMENTS

1. PREPARATION

*** The resin accents should be primed and finished ***

2. INSTALLATION

Our resin accents can be installed using different methods, dependent upon the surface on which you will be applying the ornaments.

- Utilizing screws to install our resin accents and ornaments is recommended. If properly fastened with screws, utilizing an adhesive is not necessary. For concrete ceilings, the use of anchors along with a construction adhesive is recommended.
- **Important:** Do not simply use an adhesive for installing resin products. Typically, a construction adhesive is applied for installing small, delicate pieces.

The best locations for drilling into the resin ornaments are those areas where the accent is most thick. This allows for countersinking of the screw heads – where the face detail is plain and easy to patch.

3. PAINTING & PATCHING

The outline of each accent should be caulked with a high-quality, paintable caulk.

- If screwed into place, the screw holes should be filled with a non-shrinking, premixed spackle.
- Utilize a damp paintbrush over the surface of the drying spackle. This will smooth over the screw holes and hide the patching job.
- After 24 hours of drying time, the resin accents will be able to be primed and painted. Utilize a high-quality brush.

**** For Resin Accents and Components, utilize a Marine Based Primer & a Marine Based Finish. ****

ESSENTIAL: It is important to re-paint the accent(s) over time if any cracks or peels occur from the initial painting.

- Once the resin ornaments are installed, each accent should be caulked around the edges in order to prevent water from getting behind it.